

The Adjustable™ Retrofit Valve Box by Mueller Canada Installation Procedure

The existing lid must be taken off and should be discarded. In order to prevent any liabilities, the proper AJBV-5C lid has to be installed.



The seating area of the existing top section must be broken off to allow proper installation of the retrofit section (see red casting area).



Insert retrofit unit (AJBV-5D) inside the existing valve box top section. With the paver, go over it with the hot asphalt, dig the retrofit part out, and use the asphalt left on the lid to adjust the unit to the proper height leaving it 1/4" higher than the hot asphalt. The roller compactor needs to roll straight over it to insert it into the road.



If the space between the diameter of the old top section and the retrofit section is too wide, geotextile can be installed on the retrofit section to prevent asphalt and dust infiltration.